

BTICINO > Door entry system > Spare parts > Analogue system

**336220**

Auxiliary relay to be used to drive an extra bell or different device

Technical features

N° of modules	3
---------------	---

Documentation

[!\[\]\(faf942dc3e59ce8eb64b4ac481eca7e0_img.jpg\) Instructions Sheet](#)[!\[\]\(cf531ed27e91483460120fcc057b3901_img.jpg\) Catalogue](#)